





LPX220 Configuration




1. Transfer Station Locations




Transfer Station Locations		
	Description	Order Nr.
Case A	Left Side Transfer Location, seen from front	9144 00 91
Case B	Mirrored Transfer Location	9144 00 54
Case C	Standard Transfer Station Location	
Case D	Right Side Transfer Location, seen from front	9144 00 53

2. Front Panel Location



Case A	Standard Front Panel Location
Case B	Front Panel on the left side, seen from front
Case C	Front Panel on the back side
Case D	Front Panel on the right side, seen from front

3. Connector Panel Location



Case A	Standard Connector Panel Location
Case B	Connector Panel on the right side, seen from front
Case C	Connector Panel on the front side
Case D	Connector Panel on the left side, seen from front

