

<b>Title:</b>	<b>LPX Plate Hotel – Gate Location – Transfer Station Configuration</b>	<b>ID:</b>	
		0358	
<b>Date in:</b>	<b>Response:</b>	<b>Model:</b>	<b>Author:</b>
2010-05-07	2010-05-07	LPX220	CMa

## Q:

I need help in configuring a LPX220, not sure what I get is order CASE C...or if I need to specify a CASE for the handoff/front panel and rear panel separately.

## A:

It is very easy but we need the information if it is not Case C (Standard). If there is no information we make Case C.  
You find the configuration sheet on [www.liconic.com](http://www.liconic.com) under Products, Plate Hotel, Options.

[http://www.liconic.com/products/plate-hotels/options/print/print\\_lpx220\\_configuration.pdf](http://www.liconic.com/products/plate-hotels/options/print/print_lpx220_configuration.pdf)