

Accessories – Transfer Stations Standard Transfer Station

Function

The Standard Transfer Station is a fixed station outside the StoreX system which can be accessed by the StoreX handler as well as by any external robotic system.



Main features

- Alignment pins realigning the microplates in both horizontal directions
- Easy adjustment of X / Y position, height and rotation of the transfer station
- Easy access to the microplates for external grippers
- Presence of a microplate checked by a plate sensor

Order information

	Order Nr.
STX Series, LPX Series	9118 02 75
STR Series, LPR Series	9147 00 24

Specifications

Plate Positions	1
Sensor	Plate presence sensor
Layout	Nest
Movement	None
Special	